

## 5. Transportation and installation

### 5.2.3.4 Installing LegaDrive Touch Inlay handset



Fig. 25: LegaDrive Touch Inlay handset

Install the handset at an appropriate position in the desk top.

To install the LegaDrive Touch Inlay handset under the desk top, proceed as follows:

1. Unpack handset.

|                                                                                   |                                                                                                                                                       |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>Note</b><br>Dispose of the packaging material in an environmentally friendly manner (plastic film with plastic waste, cardboard with paper waste)! |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|

2. Drill / cut out an installation hole. The cut out is illustrated below.




Fig. 26: Cut out for installing LegaDrive Touch Inlay handset with rubber fins

3. Insert the handset from above into the previously drilled hole in the desk top. The handset is installed without additional screws, the rubber fins hold it in position.




Fig. 27: Attaching LegaDrive Touch Inlay handset to example desk

### 5.2.3.5 Installing LegaDrive Touch Comfort handset



Fig. 28: LegaDrive Touch Comfort handset

Install the handset at an appropriate position underneath the desk top. To do this you will need the following tools:

- 1 x screwdriver
- 4 x screws

|                                                                                   |                                                                                                                                                           |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>Note</b><br>Please note that the handset has a Push to open function. Install the handset in the extended position to make all screw holes accessible. |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|

To install the LegaDrive Touch Comfort handset under the desk top, proceed as follows:

1. Unpack handset.

|                                                                                     |                                                                                                                                                       |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <b>Note</b><br>Dispose of the packaging material in an environmentally friendly manner (plastic film with plastic waste, cardboard with paper waste)! |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|

2. Position handset at chosen position under desk top, making sure that the handset is in easy and convenient reach. The front edge of the handset should not project beyond the edge of the desk so as not to get in the way when you are working.